

How to install the bearings into the rear upper wishbones

STEP 1

Remove both dust caps on each bearing to avoid damage during the installation process.

STEP 2

Place large ring of the supplied tool set on the press with the grooved side facing upwards (PIC 1)

STEP 3

Place wishbones on this side of the tool. It should slide perfectly into the slight groove

STEP 4

Place bearing on top of the wishbones

STEP 5

Place the small ring on the bearing according to PIC 2

STEP 6

Apply pressure until the small ring meets the wishbone. Now the bearing sits exactly in the middle of the wishbone (PIC 3)

STEP 7

Mount both dust caps and make sure the side facing the wishbone goes **INSIDE** the wishbone

STEP 8

Install wishbone and do not forget the two brass shims (one on each side of the bearing).

Place wishbone with the bearing side
on this side of the tool.

It fits perfectly into this groove.



PIC 1



PIC 2



PIC 3